

SAMSUNG

SAMSUNG

Level^{U PRO ANC}

EO-BG935

User Manual

Table of Contents

English (UK)

Français

Deutsch

Italiano

Español

Magyar

Polski

Română

Български

Hrvatski

Srpski

Português

Latviešu

Lietuvių kalba

Eesti

Nederlands

Svenska

Norsk

Suomi

Dansk

Ελληνικά

Slovenščina

Slovenčina

Čeština

Türkçe

العربية

فارسی

Русский

Українська

Қазақ тілі

English (USA)

Español (Castellano)

简体中文

繁體中文(台灣)

Français (Canada)

Português (Brasil)

한국어

Read me first

Please read this manual before using the device to ensure safe and proper use.

- Images may differ in appearance from the actual product. Content is subject to change without prior notice.
- Before using the headset, make sure it is compatible with your device.

Instructional icons



Warning: situations that could cause injury to yourself or others



Caution: situations that could cause damage to your device or other equipment



Note: notes, usage tips, or additional information

Getting started

Package contents


Check the product box for the following items:

- Headset
- Quick start guide




- The items supplied with the device and any available accessories may vary depending on the region or service provider.
- The supplied items are designed only for this device and may not be compatible with other devices.
- Appearances and specifications are subject to change without prior notice.
- You can purchase additional accessories from your local Samsung retailer. Make sure they are compatible with the device before purchase.
- Use only Samsung-approved accessories. Using unapproved accessories may cause the performance problems and malfunctions that are not covered by the warranty.
- Availability of all accessories is subject to change depending entirely on manufacturing companies. For more information about available accessories, refer to the Samsung website.

Device layout



Buttons and functions

Name	Function
Power switch	<ul style="list-style-type: none"> • Slide to turn the headset on or off. • Slide towards  and hold for approximately three seconds to enter Bluetooth pairing mode.
Multifunction/ Talk button	<ul style="list-style-type: none"> • Press to answer or end calls. • Press to play or pause multimedia files. • Press and hold for one second to reject a call or to activate ambient sound mode.
Volume buttons	<ul style="list-style-type: none"> • Press to adjust the volume during a call or media playback. • Press and hold the Volume (-) button to skip to the next file during media playback. • Press and hold the Volume (+) button to skip to the previous file during media playback. • Press and hold the Volume buttons (+ and -) simultaneously for about a second to turn the vibration feature on or off.
Noise-cancelling switch	<ul style="list-style-type: none"> • Slide to ON to activate the noise-cancelling feature.

Notification light

The notification light alerts you to the headset's status.

Status	Colour
Power on	<ul style="list-style-type: none"> • Flashes blue three times
Bluetooth pairing mode	<ul style="list-style-type: none"> • Flashes red, green, and blue
Connected via Bluetooth	<ul style="list-style-type: none"> • Quickly flashes blue three times
Incoming call	<ul style="list-style-type: none"> • Flashes blue

Status	Colour
Charging	• Continuously on red
Fully charged	• Continuously on green
During use or in sleep mode	• Off

Charging the battery

Charge the battery before using the headset for the first time or when the headset has been unused for extended periods.




Use only Samsung-approved chargers. Unapproved chargers can cause the battery to explode or damage the headset.



- You can charge the headset using the charger (sold separately).
- Using a power source other than the charger, such as a computer, may result in a slower charging speed due to a lower electric current.
- The headset can be used while it is charging, but it may take longer to fully charge the battery.
- While charging, the headset may heat up. This is normal and should not affect the headset's lifespan or performance. If the battery gets hotter than usual, the charger may stop charging.
- If the headset is not charging properly, take the headset and the charger to a Samsung Service Centre.

- 1 Open the charger port cover. Connect the headset to the USB power adaptor via the USB cable. Plug the USB power adaptor into an electric socket.






Connecting the charger improperly may cause serious damage to the headset. Any damage caused by misuse is not covered by the warranty.

- 2 After fully charging, first unplug the USB cable from the headset, and then unplug it from the computer or the electric socket.



- To save energy, unplug the charger when not in use. The charger does not have a power switch, so you must unplug the charger from the electric socket when not in use to avoid wasting power. The charger should remain close to the electric socket and easily accessible while charging.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.

Turning the headset on and off

- : ON
- : OFF
- : Bluetooth pairing mode



Follow all posted warnings and directions from authorised personnel in areas where the use of wireless devices is restricted, such as aeroplanes and hospitals.

Connecting via Bluetooth

Bluetooth

About Bluetooth

Bluetooth is a wireless technology standard that uses a 2.4 GHz frequency to connect to various devices over short distances. It can connect and exchange data with other Bluetooth enabled devices, such as mobile devices, computers, printers, and other digital home appliances, without connecting via cables.

Notices for using Bluetooth

- To avoid problems when connecting your headset to another device, place the devices close to each other.
- Ensure that your headset and the other Bluetooth device are within the Bluetooth connection range (10 m). The distance may vary depending on the environment the devices are used in.
- Ensure that there are no obstacles between the headset and a connected device, including human bodies, walls, corners, or fences.
- Do not touch the Bluetooth antenna of a connected device.
- Bluetooth uses the same frequency as some industrial, scientific, medical, and low power products and interference may occur when making connections near these types of products.
- Some devices, especially those that are not tested or approved by the Bluetooth SIG, may be incompatible with the headset.
- Do not use the Bluetooth feature for illegal purposes (for example, pirating copies of files or illegally tapping communications for commercial purposes).

Connecting to other devices

This headset is compatible with Bluetooth-enabled devices.


- 1 **Headset** Slide the Power switch to the right and hold it for approximately three seconds to enter Bluetooth pairing mode.

When you turn on the headset for the first time, it automatically enters Bluetooth pairing mode.

- 2 **Other device** Activate the Bluetooth feature and search for Bluetooth devices.

For more information, refer to the other device's user manual.

- 3 **Other device** Tap **Samsung Level U Pro ANC (0000)** from the list.



- The PIN for the headset is the four-digit number in parenthesis displayed on the other device's Bluetooth settings screen. The number differs depending on the headset.
- Once devices are paired, recently connected devices automatically connect to your headset whenever you turn it on.
- If the Bluetooth connection fails or other device cannot locate the headset, remove the device's information from the other device's list. Then, try to connect again.
- If the headset does not work properly, restart it or try to pair the devices again.
- The Bluetooth connection range and sound quality may vary depending on the connected devices.

Connecting additional devices

The headset can connect to up to two Bluetooth-enabled devices at the same time. When you connect the headset to two devices, the last device you connect is recognised as the primary device. The other device is recognised as the secondary device.

- 1 Connect the headset to a device via Bluetooth.
- 2 Slide the Power switch to the right and hold it for approximately three seconds to enter Bluetooth pairing mode.

The first device will be disconnected.

- 3 Connect the headset to a second device.
- 4 Reconnect the headset to the first device.



This feature may not be supported on some devices.

Reconnecting or disconnecting the devices

Reconnecting the devices

If the Bluetooth connection ends due to the distance between the devices, bring the devices closer together within a certain period of time. The devices will automatically reconnect.

If the Bluetooth connection ends because of a device malfunction, access the Bluetooth menu on the connected device to pair them again.

Disconnecting the devices

Slide the Power switch to the right and hold it for approximately three seconds. Then, the connection ends and the headset enters Bluetooth pairing mode.

You can also end the connection by turning off the headset. When you turn on the headset again and the devices are in range, the headset automatically connects with the most recently paired device.



Noise may occur if the Bluetooth connection is disconnected improperly.

Using the headset

Wearing the headset



The headset contains magnets in its earbuds. The American Heart Association (US) and the Medicines and Healthcare Products Regulatory Agency (UK) both warn that magnets can affect the operation of implanted pacemakers, cardioverters, defibrillators, insulin pumps or other electro medical devices (collectively, “Medical Device”) within the range of 15 cm (6 inches). If you are a user of any of these Medical Devices, **DO NOT USE THE HEADSET UNLESS YOU HAVE CONSULTED WITH YOUR PHYSICIAN.**



- Do not store your headset near magnetic fields. Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields.
- Do not bend or twist the headset excessively.
- Do not apply excessive pressure to the headset.
- Do not pull on any part of the headset excessively.


Wearing the headset

Insert the earphones into your ears or wear the headset around your neck while the earphones are not connected to each other.





Connecting the earphones

Connect the earphones to each other using the built-in magnets.



The magnetic sensor may not work properly if the earphones are not connected properly.



Using the headset

Various features are available when the headset is connected to another device.



The following descriptions are based on a Samsung mobile device running Android 5.0. Some features may not be available depending on the connected device.

Calling features

Answering a call

When a call comes in while you are wearing the headset, the headset will beep and vibrate. Press the Talk button to answer the call.

When a call comes in while the earphones are connected, the headset will vibrate. Separate the earphones and put them on your ears. When you separate the earphones, the call will be received.



- When the headset is connected to two devices and both devices receive calls simultaneously, you can only answer the primary device's call.
- When you play a multimedia file from one device, you can still answer calls from the other device.

Rejecting a call

Press and hold the Talk button for one second or connect the earphones.

Adjusting the volume

Press the Volume button.

Switching sound output

Use the connected device's call features to switch call audio between the headset and the device.

Ending a call

Press the Talk button or connect the earphones.

Playing multimedia files

Control media playback, such as music and videos, using the Multifunction button.

Playing and pausing a multimedia file

Press the Multifunction button. The most recently-played music file will play automatically in the default music app installed on the connected device.

During playback, press the Multifunction button to pause playback or connect the earphones. To resume playback, press the Multifunction button again.



When two connected devices are simultaneously playing multimedia files, the headset will stream from the device that started playing a file first. When you pause the currently-playing file, the file playing on the other device will play automatically.

Skipping to the next multimedia file

Press and hold the Volume (-) button to skip to the next file during playback.

Skipping to the previous multimedia file

Press and hold the Volume (+) button to skip to the previous file during playback.

Adjusting the volume

Press the Volume button.

Removing background noise

Use this feature to set the headset to remove background noise.

Slide the Noise-cancelling switch to ON to activate the noise-cancelling feature. The notification light flashes green when the feature is turned on.

Slide the Noise-cancelling switch to OFF to deactivate the noise-cancelling feature. The notification light flashes yellow after the feature is turned off.



Noise may occur when you touch the noise-cancelling microphone.

Using ambient sound mode

Hear your surroundings while you are listening to music outdoors, so you can quickly detect any potentially dangerous situations.

Press and hold the Multifunction button for one second to activate the feature. The headset will beep and vibrate when the feature is turned on.

Press and hold the Multifunction button for one second again to deactivate the feature. The headset will beep after the feature is turned off.



- In ambient sound mode, feedback may occur when adjusting the volume or touching the microphone.
- In ambient sound mode, you can still hear loud external sounds.

Using Samsung Level

On the connected device, download the Samsung Level app from Google Play Store or Galaxy Apps. With the app, you can check the remaining battery power and adjust the volume. You can also set the headset to notify you via voice notification or vibrate when you have notifications on the connected device. For more information, refer to the app's help menu.



The Samsung Level app is compatible with Samsung mobile devices running Android operating system 4.2.2 or later. Some features may differ or may not work on your headset depending on the connected device or the operating system.

Using the ultra high quality Bluetooth (UHQ-BT) feature

If a connected mobile device supports the ultra high quality Bluetooth (UHQ-BT) feature, you can listen to UHQ audio using the headset. Use the Samsung Level app on the connected mobile device to deactivate the UHQ-BT feature. For more information, refer to the Samsung Level app's help information.



- When you use the Bluetooth feature to listen to UHQ audio, the headset's battery efficiency and the maximum Bluetooth range (10 m) may be reduced.
- Visit www.samsung.com to view the product specifications for the connected mobile device to confirm that it supports the UHQ-BT feature.

Sharing audio via Sound with Me

Share audio that you are listening to on your headset with other headsets that support the Sound with Me feature.

Ensure that the headset that you want to share audio with is turned on.



- Your headset must be connected to a mobile device, such as a smartphone or tablet. If your headset is connected to more than one mobile device, you cannot share audio with other headsets.
- If the headsets are more than five metres apart while sharing audio, the signal quality may be poor.
- If the other headset is turned off during sharing, it will be disconnected from your headset. When you turn it on again, it will automatically reconnect to the mobile device that it was connected to before sharing audio.
- Visit www.samsung.com to view the product specifications for the other headset to confirm that it supports the Sound with Me feature.

Using the Power switch

To activate audio sharing, slide the power switch of the other headset to the right two times to enable it to be located. Then, slide the Power switch of your headset to the right once. The audio you are currently listening to will be shared with the other headset.

To deactivate audio sharing, slide your headset's Power switch to the right and hold it for about a second.

Using Samsung Level

On the connected mobile device, launch the Samsung Level app to share audio with other headsets.

For more information, refer to the app's help information.

Appendix

Troubleshooting

Before contacting a Samsung Service Centre, please attempt the following solutions.

Your headset does not turn on

When the battery is completely discharged, your headset will not turn on. Charge the battery completely before turning on the headset.

Your headset freezes

If the headset's audio experiences any problems, such as freezing or distorting, try to resolve it by turning off the headset and then turning it on again.

If the headset is still unresponsive, end the Bluetooth connection and reconnect it. To do this, slide the Power switch towards **✖** and hold it for approximately three seconds to enter Bluetooth pairing mode. When the headset enters Bluetooth pairing mode, connect the devices again, and then check the operation of the headset.

If the problem is still not resolved, contact a Samsung Service Centre.

The battery does not charge properly (For Samsung-approved chargers)

Ensure that the charger is connected properly.

If the problem is still not resolved, contact a Samsung Service Centre.

Another Bluetooth device cannot locate your headset

- Ensure that your headset is in Bluetooth pairing mode.
- Restart your headset and search for the headset again.
- Ensure that your headset and the other Bluetooth device are within the Bluetooth connection range (10 m).

If the tips above do not solve the problem, contact a Samsung Service Centre.

Your headset cannot connect to another Bluetooth device

- Ensure that your headset and the other Bluetooth device are within the maximum Bluetooth range (10 m).
- On the device you want to connect with, disconnect all paired devices and try to connect again.

Bluetooth connection is often disconnected

- If there are obstacles between the devices, the operating distance may be reduced.
- Ensure that your headset and the other Bluetooth device are within the maximum Bluetooth range (10 m).
- When using the headset with other Bluetooth devices, the connection may be affected by electromagnetic waves. Use the headset in environments with fewer wireless devices present.

You cannot hear others speaking

- Adjust the device volume.
- Adjust the volume on the connected device when you cannot hear sounds on your headset at full volume.

Sound echoes during a call

Adjust the volume by pressing the Volume button or move to another area.

Others cannot hear you speaking on a call

- Ensure that you are not covering the built-in microphone.
- Ensure that the microphone is close to your mouth.

Audio quality is poor

- Wireless network services may be disabled due to issues with the service provider's network. Ensure to keep the headset away from electromagnetic waves.
- Slide the Noise-cancelling switch to ON to activate the noise-cancelling feature.
- Ensure that your headset and the other Bluetooth device are within the maximum Bluetooth range (10 m).
- You may experience drops in volume or noise depending on the connected device's volume. To avoid this, appropriately adjust the connected device's sound.

The headset works differently as described in the manual

- Available functions may differ depending on the connected device.
- Some features cannot be used when two devices are connected with the headset at the same time.

The battery depletes faster than when first purchased

- When you expose the headset or the battery to very cold or very hot temperatures, the useful charge may be reduced.
- The battery is consumable and the useful charge will get shorter over time.